EN

COGITO™ POP

Quick Start Guide

NOTIFICATION LED
icon & vibrate with optional beeps

COMMAND

SET TIME
Pull 1/2 way and turn to set the time

POWER
Power on/off > 3 sec
Check connection Short press

Pairing: Press COMMAND + POWER buttons until 1st beep (approx. 3 sec) and all icons will blink every 2 sec.

Reset the watch: Press and hold the COMMAND + POWER buttons until 2nd beep (approx. 9 sec).

SMS and Social media posts on Facebook & message notification from WhatsApp, WeChat, Skype and more...

Other info such as calendar events, reminder and more...

Email

All icons blink & vibrate for urgent alerts such as,
– Incoming, missed calls & voice mail
– Find your watch
– Find your phone*

* Currently available for iOS only. Android support will be announced in coming app release.

Step 1: Download the Connected Watch App

For iOS users: Search for the "Connected Watch" App in the App Store.

Compatible with iOS 7 devices that support Bluetooth® Smart technology such as the iPhone 5s, iPhone 5c, iPhone 5, iPhone 4s, iPad mini, iPad (3rd and 4th generation), and iPod touch (5th generation).

For Android users: Download the "Connected Watch" App from Google Play.

The app is available for selected Android 4.3 and Android 4.4 devices that support Bluetooth® Smart technology. Currently compatible with Samsung Galaxy S3, S4, S4 Mini, S4 Active, Note 2, Note 3, HTC One, Nexus 5, etc.
Visit www.cogitowatch.com for the latest compatibility list. Contact us if Google Play is not supported in your country.

Step 2: Pair and connect the COGITO watch with your mobile phone or tablet

1. Set the watch into PAIRING mode by pressing the COMMAND + POWER buttons until 1st beep (approx. 3 sec) and all icons will blink every 2 sec.
2. **For iOS7 user:** Open your phone's Bluetooth settings and select "COGITO POP" in the device list. Press "PAIR" when prompted.
   For Android user: Open the Connected Watch App and tap the Device List icon at the bottom left. The app will search for your watch accordingly. Select "COGITO POP" in the device list to connect.

Step 3: Customize your COGITO watch's notification settings

Tap the Notification Settings icon at the top right of the Connected Watch App (iOS7 and Android) and select which notifications do you wish to receive on your COGITO watch.

To mute or unmute the watch – press and hold the COMMAND button for 9 sec.

To acknowledge the notification – press any button or check the notification on your mobile phone or tablet.

To send a command – press the COMMAND button. (command action please refer to the setting of the app)

To check connection – press the POWER button – if the watch beeps and the icons blink once then the connection is active. If the icons blink 3 times, the connection is not active.

To find the COGITO watch – The watch beeps and blinks when tapping the "find my watch" icon in the Connected Watch App.

To find your phone (for iOS 7 users only) – Your device beeps when tapping the COMMAND button. Please refer to the settings in the Connected Watch App.

To activate out of range notification – After tapping the out of range icon , the watch beeps and blinks when your phone and watch are apart from each other. Range for the Bluetooth is about 10-20 meter, distance are varies based on the devices and environment.

EN

Replacing the connected system battery:





1. Open the back case of the watch to remove the old battery.
2. Now replace with new battery.
3. Carefully replace the back case of the watch, ensuring that the o-ring is correctly seated (for a water tight seal).

Replacing the analog movement battery:



1. Open the back case of the watch and remove the CR2032 cell button battery.
2. Remove the protective sticker and carefully set it aside.
3. Remove analog system battery located beneath the protected sticker. (model SR626SW, battery life up to 3 years**)
4. Carefully put back the protective sticker.
5. Insert the CR2032 battery and carefully replace the back case of the watch ensuring that the o-ring is correctly seated (for a water tight seal).

** Battery life may vary depending on the volume of the notification, brand and condition of battery.

Caution advised by certification: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

One year limited warranty

Register your product by setting-up a CONNECTEDEVICE account in the Connected Watch App. You will need to keep your original receipt as proof of purchase.

To keep your watch in good condition and to avoid voiding the warranty:

- Do not expose the watch to excessive pressure, impact, dust, open flames or extreme temperatures.
- Operating temperature: -20 to +55C. (-4 to +131F)
- Always ensure the back case and o-ring is correctly in place and the watch is tightly sealed before exposing the watch to any moisture or liquid.
- Do not attempt to repair or modify the watch yourself. Service and maintenance should be performed by authorized technicians.
- 10 ATM/100 M of water resistance means that your watch can be worn for most indoor or outdoor activities, including most water sports. Suitable for recreational surfing, swimming, snorkeling, sailing and water sports. NOT suitable for diving.
- Avoid submerging the watch for an extended period of time.
- To maintain water resistance, do not press any buttons or pull out the crown while under water.
- Keep the front glass away from sharp or hard objects to prevent scratches.
- Exposure to high or low temperatures or frequent successive alerts may shorten battery life.
- Keep the watch, accessories and any small parts out of the reach of children.

For support, please email us at support@cogitowatch.com

COGITO™ POP

For more information about the watch and Connected Watch App, visit cogitowatch.com

Thank you for supporting COGITO™